

**42 Silverton Convertible  
Hard Top Enclosure  
Packing List  
Hull #185 to 259**

- \_\_\_ **100 Flex Rail Screws**
- \_\_\_ **36 Lift the Dot Screw Studs**
- \_\_\_ **12 7/8" Lift the Dot Windshield Clips**
- \_\_\_ **24 7/8" Glove Button Windshield Clips**
- \_\_\_ **12 Lift the Dot Sockets and Plates**
- \_\_\_ **24 Glove Button Sockets and Caps**
- \_\_\_ **11 Pre-made pieces of White vinyl track**
- \_\_\_ **1 Flex Rail Screw Tip**



1. The track package consists of 11 pieces of track. The 5' 6" pc is for the front. Locate the center of the track on the center of hardtop. Keep the track about a 1/2" from the feature on hardtop, as shown in picture. Secure with the flex rail crews provided, screws should be installed every 6", caulk all holes before installing screws.



2. Once the 5' 6" track is secure add a 7' 6" pc to both ends. Track should extend around corner all the way to the arch style support. Trim ends of track 1in passed aluminum diverter on each side; keep the track tight to the diverter as shown in the picture.



3. The aft section consists of two tracks 7' 6". Start at back of arch hard top support, keep the track tight in corner and work back. Work around corner to the back center. Some of the track will need to be trimmed where the port and starboard track meet.





4. The four 4ft tracks are for the front and back of the arch style support.  
Secure with the flex rail screws provided as shown in these pictures, start on the center top and flare out to the bottom. This will help the track shed water.  
Be sure and caulk all tracks before installing enclosure.



5. Slide all 8 panels into track and then zip all panels together. The front buttons are marked but not installed to allow for adjustment. Some special tools are needed to install these fasteners. Call 1(888) 245-0011 if you need help finding these tools.





6. The aft section of the enclosure is secured with LTD studs. Install the side curtains first then work across back. Work from center out installing 1 or 2 studs at a time until completion. There are two 6" tracks not shown in these pictures. Locate the Velcro flaps on the side curtains. Install the tracks to hold the flaps in place. Caulk all holes and track.