

3700SY Maxum

Forward and Aft Bimini Tops

___ 2 Boots

___ 6 #8 x 1/2in Pan head screws



1. Remove the rope zippers from tops and slide them into the track already installed on the arch. Use the 1/2in screws provided to pin the center of the rope zipper to the center of the arch. Pull the slack out to the ends of the track and pin in place.



2. Zip the tops to the arch, then zip the pockets to the frame. Release the quick pin for the struts to make it easier to get the pocket around the frame. Then place the struts back into the mounts.