

33C SILVERTON
WINDSHIELD COVER

PACKING LIST

<u>Hardware</u>	<u>P/N</u>
___ 14pc Glove button screw studs	1039312
___ 2pc Lift the dot studs	16360



Install the center button on the center of the windshield about 1in down from the glass. Work out in each direction to the corners installing one button at a time. Using the glove button studs provided.

33C SILVERTON
WINDSHIELD COVER



After the front is complete install the lift-the-dot up under the bridge overhang. Pull the cover around the corner until the back edge reaches the seam in the glass. Secure it in place with the stud provided. Pull the back corners down and back, mark and install the remaining studs. Repeat on the opposite side.