

34C SILVERTON
WINDSHIELD COVER
PACKING LIST

Hardware

P/N

____ 18pc Glove button screw studs

1039312

____ 2pc Lift the dot studs

16360



Install the center button on the center of the windshield about 1in down from the glass. Work out in each direction to the corners installing one button at a time. Using the glove button studs provided.

34C SILVERTON
WINDSHIELD COVER
PACKING LIST



After the front is complete install the lift-the-dot up under the bridge overhang. Pull the cover around the corner until the back edge reaches the seam in the glass. Secure it in place with the stud provided. Pull the back corners down and back, mark and install the remaining studs. Repeat on the opposite side.