

**42 Silverton Convertible
Hard Top Enclosure
Packing List
Hull #135 to 184**

- _____ **100 Flex Rail Screws**
- _____ **5 Pad Eyes**
- _____ **10 #8 x 3/4" Oval Head Screws**
- _____ **14 Lift the Dot Screw Studs**
- _____ **12 7/8" Lift the Dot Windshield Clips**
- _____ **24 7/8" Glove Button Windshield Clips**
- _____ **12 Lift the Dot Sockets and Plates**
- _____ **24 Glove Button Sockets and Caps**
- _____ **9 Pre-made pieces of White vinyl track**
- _____ **1 Flex Rail Screw Tip**



1. The track package consists of 9 pieces of track. The 5' 6" pc is for the front. Locate the center of the track on the center of hard top. Keep the track about a 1/2" from the feature on hardtop, as shown in picture. Secure with the flex rail crews provided, screws should be installed every 6".



2. Once the 5' 6" track is secure add a 7' 6" pc to both ends. Track should extend around corner all the way to the arch Style support.



3. the aft section consists of two tracks 7' 2". Short at center and secure track with flex rail screw provided. Bend track around corner, using screws more frequently in corner. Continue to end and repeat on the opposite side.



Listing 4 is for pictures above and below

4. The four 3' 9" tracks are for the front and back of the arch style support. Secure with the flex rail screws provided as shown in these pictures. Be sure and caulk all track before installing enclosure.





5. Slide all 8 panels into track and then zip all panels together. The front buttons are marked but not installed to allow for adjustment. Some special tools are needed to install these fasteners. Call 1(888) 245-0011 if you need help finding these tools.





6. The aft section of the enclosure is secured with Bunji cords. Mark each location with a pad eye and secure with #8 x $\frac{3}{4}$ " screws. The sides secured with LTD studs.