

42C SILVERTON
WINDSHIELD COVER
PACKING LIST

Hardware

____ 6pc Glove button screw studs

____ 12pc Lift the dot studs



Install the center button on the center of the windshield about 1” down from the glass. Work out in each direction to the corners installing one button at a time. Using the glove button studs provided.



After the front is complete install the lift the dot stud up under the bridge overhang. Pull the cover around the corner until the back edge reaches the seam in the glass. Secure it in place with the stud provided. Pull the back corners down and back, mark and install the remaining studs. Repeat on the opposite side.