

3500SY Maxum Aft Enclosure Packing List

_____ 2 #8x1/2" Pan Head Screws _____ 30 Glove Button Studs



Once rear top is pulled tight zip and Velcro all five panels in place.



Start installing the aft enclosure at the door. Align the door flap evenly to door, pull tight and install snaps on each zipper. Work away from door in either direction. Mark one button at a time, pull tight and smooth until all snaps are installed.



Once the installation is complete the rope that holds the top to the arch should be screwed in place. The same should be done to all six pieces of rope.