

3500SY Maxum Forward Enclosure Packing List

___ 36 7/8" LTD Windshield Clips

___ 4 LTD screw studs

___ 2 #8 x 1/2in Pan head screws



Zip and Velcro front five panels in place.



Begin installing in front center. Mark each button one at a time, pulling the curtain tight and smooth. Work all the way around to the end of the windshield.



Once the installation is complete the rope that holds the top to the arch should be screwed in place. The same should be done to all six pieces of rope.