



Once the track and frame are installed the tops can be zipped in place. The number of pockets for the frame can identify the correct top. Make sure the center of the top is on the center of the arch before pulled tight. Then zip and Velcro front five panels in place.



Once rear top is pulled tight zip and Velcro all five panels in place.



Begin installing in front center. Mark each button one at a time, pulling the curtain tight and smooth. Work all the way around to the end of the windshield.



Start installing the aft enclosure at the door. Align the door flap evenly to door, pull tight and install snaps on each zipper. Work away from door in either direction. Mark one button at a time, pull tight and smooth until all snaps are installed.



Once the installation is complete the rope that holds the top to the arch should be screwed in place. The same should be done to all six pieces of rope.

3500SY
BIMINI ENCLOSURE
2000



3500SY Enclosure Packing List

Canvas

___ 2 Bimini Tops w/ Boots

___ 8 #8x1/2" Pan Head Screws

___ 26 Glove Button Studs

___ 36 7/8" LTD Windshield Clips