

3500SY Maxum Cockpit Cover Packing List

___ 22 7/8" Glove Button Windshield Clips

___ 2 #8x1/2" Pan Head Screws

___ 16 Glove Button Studs

___ 16 Glove Button Caps

___ 16 Glove Button Sockets

___ 2 49" Flex Rail track

___ 18 Flex Rail screws

___ 2 Tent Poles

___ 2 7/8" LTD Windshield clips



Open the cockpit cover and stretch it out over the cockpit. Align the cut outs in the cover with bimini frame and arch. Find the front center snap and install a windshield clip provided on center of windshield.



Attach straps to rail centering cover on the boat and pull tight. Install the buttons on port and starboard sides work front and back at the same time.



Keep the cover under the windshield wiper. Mark one button at a time, work around the corner pulling the material smooth between each button. Install the windshield clips all the way back to the arch. Install flex rail to inside of arch with flex rail screws. Slide velcro rope into truck & pin in place with 1/2" screws.