

## 3700SY Maxum

### Aft Enclosure

\_\_\_ 32 Glove button studs

\_\_\_ 2 63in Flex Rail

\_\_\_ 26 Flex Rail screws

\* Flex Rail screw bit is packed with frame hardware



1. Zip all five panels to the top and to each other. Begin installing at the transom door with the buttons evenly spaced on each side of the opening. Work across the back and around the corners. Use Glove button studs provided.



2. Begin installing the 63in track provided inside bimini track below top mount as shown in the picture. Work down the arch keeping the track tight to the mounts. Repeat on the opposite side. Remove the rope zipper from the side panels and slide into the track. Zip the panels down and install the remaining glove buttons on the bottom of each side.