

3700SY Maxum

Forward Enclosure

___ 36 7/8in Lift the Dot windshield clips

___ 3 Lift the Dot screw studs

___ 2 47in Flex Rail

___ 20 Flex Rail screws

- Flex Rail screw bit packed w/ frame hardware



1. Zip all four panels to the top and to each other. Begin installing Lift the Dot windshield clips provided at the center of the windshield. Mark one button at a time and install. Mark out around the corner to the sides.



2. Use the track guide to draw a line at 1in from the front edge of the arch for the front side panels.



3. Begin installing the 47in track provided at the bottom base of the arch and work up so that the tracks over lap as shown in previous picture. Secure the track with the Flex Rail screws and bit provided. Repeat on opposite side.

3



4. Remove the zip rope from the side panels and slide into the track. Zip the panels to the track and finish installing the remaining Lift the Dot studs provided.

4